


LED Strip Studio (LSS) Ethernet Update

To update LSS Ethernet please perform these steps:


1. Copy **lssnet.bin** and **bootldr.cfg** files from **Firmware** directory to **root** of FAT-32 formatted SD-card.
2. Insert the card to LSS Ethernet.
3. Turn off the LSS Ethernet (disconnect from power).
4. Turn on the LSS Ethernet.

The device will start update, which takes about 30 seconds. During the time the device looks like not working. But don't worry, it will start after.

You can also check whether update has been successful over Ethernet. Use attached **LEDNETInfo.exe** software from **Device Check** directory:



In the **IP** box please set your device IP. Then press **Get Info** button and you should get following information:



The most important is the information in the **Firmware version** line.